

Timberguard Primer

Version 1 June 2013

PRODUCT DESCRIPTION

Timberguard Primer is a water based acrylic penetrating primer which provides excellent sealing properties and resistance to moisture ingress. It binds chalky surfaces and promotes excellent adhesion for use under acrylic coatings. The primer will assist in protection of the substrate including fungal infestation.

AREAS OF USE

- As an excellent penetrating primer for the application of Flexitex Systems or Tredgrip
- As a penetrating primer on clean concrete and masonry in preparation for the application of Flexitex Systems or Tredgrip.
- Ultra V Primer is not to be applied to any composite wood products such as Innowood, Biowood or Vocana due to those products density and being unable to penetrate the surface. For all other composite brands check with the manufacturer / distributor for details of coating suitability.
- Do not apply Timberguard Primer to any timber that has been oiled without first thoroughly washing the timber as per Timber Prep [Step 1](#) application process to ensure that the primer will be able to penetrate the substrate.

TYPICAL PRODUCT DATA

Colour	Clear
Volume Solids	30%
V.O.C.	Nil
Odour	Low Odour
Dry Time	30 minutes @ 25°C atmospheric temperature
Clean Up	Clean equipment with water
Applicators	Flat Lambswool applicator, long bristle brush and spray

APPLICATION

For best results apply the Primer with a Lambswool applicator and apply to 3 boards at a time to maintain a wet edge, reducing the risk of overlap marks. Ensure an even coverage and do not apply too thinly to enable the product to fully penetrate. Do not allow the product to pool, remove any excess product immediately. Coat all end grain and sides of each timber piece and if possible also coat the bottom of the decking boards. If coating vertical walls the best method of application is to use an airless or air assisted spray gun. Do not apply heavy coats as the primer will sag, apply at low pressure using a fine tip.

Wait for a minimum of 30 minutes at 25°C for the Primer to dry before applying the Tredgrip or Flexitex Systems.

Note: Uncoated timber that has been exposed for a long period of time to the sun may need two coats of the primer to achieve maximum protection for the timber. Wait 1 hour between coats to achieve proper adhesion.